



### **Anchor Kit:**

Contents:

- 4 anchor sleeves
- 4 each 3/8" x 2" hex-headed bolts,
- 4 flat washers

Instructions:

Drill 5/8" hole in concrete to match the hole pattern on bottom of unit or the feet on the benches. Sink the sleeve into the drilled hole, insert washer and bolts through hole in bottom of unit and tighten.

**\*\*Not all units require four anchor sleeves.\*\***



### **Lid Cable Kit:**

Contents:

- 24" of 1/8" encapsulated cable
- 2 aluminum ferrules

Instructions:

Loop the cable through hole in lid and then through can. Thread ends of the cable through the holes in the ferrule and crimp using pliers or crimping tool.

